## TEST CERTIFICATION

May 11, 2007

Japan Spinners Inspecting Foundation

1-18-15 Uemachi, Chuo, Osaka 540-0005 Japan

Phone: 06-6762-5887 -- Osaka

Fax: 06-6762-8588 -- Osaka

## To: Dynic Corporation

Please find the following test results to the soil sample that were given to us.

Access Date: Apr 27, 2007

Product Description: Antibacterial, antivirus, anti-mold and anti-allergen filter

Quantity: one

[Testing Category]

Anti- bacterial Test

[Testing Strain]

Staphylococcus Aureus ATCC 6538P

[Testing Method]

In accordance with JIS L 1902 Standardized Test (Bacterial fluid absorption method)

Measurement of bacteria: pour plate method

#### [Results]

Planting numbers (A)	2.4×10 <sup>4</sup>	log A 4.4
Number of bacterial taken from non-processed	$9.0\! imes\!10^{6}$	log B 7.0
cloth (B)		

(Non-processed cloth is applied for the standard cloth.)

 $\log B - \log A = 2.6 > 1.5$  Test is valid.

Sterilization Active Value:  $\log A - \log C$ 

Bacteriostatic Active Value: log B - log C

Soil sample	Number of	Number of	Sterilization	Bacteriostatic
	Bacterial log-	viable bacteria	Active Value	Active Value
	С			
Antibacterial,	< 20	Less than 1.3	More than 3.1	More than
antivirus, anti-				5.7
mold and anti-				
allergen filter				

Remark: Surfactant of Tween 80 is added 0.05 percent for the testing bacterial.

The test result is subject only to the soil samples given to us and does not represent the consignment.

## TEST CERTIFICATE

May 11, 2007

Japan Spinners Inspecting Foundation

1-18-15 Uemachi, Chuo, Osaka 540-0005 Japan

Phone: 06-6762-5887 -- Osaka

Fax: 06-6762-8588 -- Osaka

# To: Dynic Corporation

Please find the following test results to the soil sample that were given to us.

Access Date: Apr 27, 2007

Product Description: Antibacterial, antivirus, anti-mold and anti-allergen filter

Quantity: one

[Testing Category]

Anti- bacterial Test

[Testing Strain]

Klebsiella pneumoniae ATCC 4352

[Testing Method]

In accordance with JIS L 1902 Standardized Test (Bacterial fluid absorption method)

Measurement of bacteria: pour plate method

#### [Results]

Planting numbers (A)	2.4×10 <sup>4</sup>	log A 4.4
Number of bacterial taken from non-processed	$9.0 \times 10^{7}$	log B 7.5
cloth (B)		

(Non-processed cloth is applied for the standard cloth.)

 $\log B - \log A = 3.1 > 1.5$  Test is valid.

Sterilization Active Value:  $\log A - \log C$ 

Bacteriostatic Active Value: log B - log C

Soil sample	Number of	Number of	Sterilization	Bacteriostatic
	Bacterial log-	viable bacteria	Active Value	Active Value
	C			
Antibacterial,	< 20	Less than 1.3	More than 3.1	More than
antivirus, anti-				6.2
mold and anti-				
allergen filter				

Remark: Surfactant of Tween 80 is added 0.05 percent for the testing bacterial.

The test result is subject only to the soil samples given to us and does not represent the consignment.